

BOAT WEIGHT

1. CONSULT RULES FOR ALLOWABLE ITEMS TO REMAIN ON BOARD.
2. INSPECT ALL COMPARTMENTS FOR WATER, AND THOROUGHLY DRY THEM ALL.
3. USE CLASS LOAD CELL (OR OTHER APPROVED METHOD). USE STRAPS OR SLINGS PROVIDED AND INSTALLED BY OWNER.
4. RECORD OBSERVED WEIGHT.

CORRECTOR WEIGHTS

1. CONFIRM IF USING ANY PORTION OF THE 20# ALLOWED TO BE PLACED ANYWHERE IN THE BOAT.
2. RECORD THE TOTAL WEIGHT OF ALL "ADDITIONAL CORRECTOR" WEIGHTS.
3. RECORD THE FORE AND AFT DISTANCE SEPARATING EACH HALF OF THE "ADDITIONAL CORRECTORS".

FLOTATION

1. APPLY BUILT IN VOLUME OF 8 CU FT FOR THE BUNK TANKS BETWEEN F53 AND F169, IF USED.
2. APPLY BUILT IN VOLUME OF 2.5 CU FT FOR AREA FORWARD OF F18, IF SEALED.
3. CALCULATE THE VOLUME AND APPLY ANY OTHER SEALED HULL CHAMBER.
4. APPLY THE MANUFACTURER SPECIFIED VOLUME OF ANY SECURED AIR BAGS OR CHAMBERS.
5. RECORD THE TOTAL OF ALL FLOTATION PROVIDED.